

TRUCK WASH

Premier - Instructions



pH:	11.0 -11.3
Caustic:	NO
Degreaser:	SLIGHT
Phosphates:	YES
Gloss Enhancers:	YES
Rinsing:	EXCELLENT
SuperFlo Polymer:	YES - HEAVY CONCENTRATIONS
Packaging:	One 40-pound carton of base powder that will yield 55 gallons of liquid detergent concentrate.

Premier is a professional strength alkaline cleaning agent specifically formulated for house washing applications when aggressive cleaners are not required such as new construction. Premier is safe to use on all colors but we still recommend any time you are unsure of suitability do a test on a small inconspicuous area.

Mixing Instructions: Read and understand these instructions before starting to mix this product. Use warm water (never hot - not to exceed 120 degrees F). Warm water helps powders go into solution more easily. Hot water, on the other hand, will blow apart many of the surfactants utilized in the formulary process. It is possible to use cold water but additional manual agitation may be required. Use a clean poly drum; fill it approximately 50% full with warm water. Place the nozzle of a high-pressure washer close to the bottom of the drum and continue filling while adding the powder slowly. When the drum is 90% full all the powder should have been added. Continue filling until the drum is full. The result is 55 gallons of liquid concentrate that is now ready for use.

Dilutions: The amount you dilute Premier depends on many factors and cannot be covered by one statement. The following guidelines are a starting point from which you should adjust. Chemical dilution rates need to be adjusted because of weather conditions, cleaning difficulty, washing method used, including PSI and whether or not you brush, and desired result. Remember that a typical downstream injector is already diluting the product approximately 1 part detergent to 9 parts water (10%) for most injectors or 2 parts product to 8 parts water (20%) with an Allison super suds sucker injector.

Starting Dilution: 1 part product to 70 parts water
(Salesmen will tell you very high dilution rates attempting to make you think their product is the best. Actual washing experience is the only way to determine what is right for you. Remember, detergent is much cheaper than labor.)

Washing technique (single step): Coat the surface to be cleaned with Premier using low pressure High-pressure wash the surface removing the detergent and released dirt. Never apply to an area larger than you can wash off prior to the product drying on the surface. Apply Premier from the bottom upward and rinse from the top downward. Do not apply to the surface under high pressure when washing homes. If you do you will be forcing the detergent into small areas, up under the siding and around window trim. When this happens it is impossible to rinse those areas. You will leave the job site thinking all is well only to receive a phone call from the customer saying that the detergent has 'dripped' from those areas and 'streaked' the surface. Occasionally this may cause a situation of irreversible damage.

Washing technique (two step): Apply the first step, which is usually an acid product, to the surface to be cleaned. Immediately apply Premier on top of the first step product. You will see the pollutant explode from the surface. High-pressure wash the surface removing the detergent and released dirt. Never apply detergent to an area larger than you can wash off prior to the detergent drying on the surface.

Note: It is important to always rinse well and when you think you are done - rinse again. This should be common practice with all cleaning solutions. Pay special attention to horizontal surfaces that may trap detergent allowing it to run down onto surfaces after you have washed them. Examples of where this occurs would be run-off from tractor roofs and trailer tops. Try not to put detergent in these areas, if you do be sure to get it rinsed off to leave a streak free surface.

Recommended surfaces that can be cleaned with Premier: Vinyl & Aluminum siding, Painted wood, Brick, Stucco.
Not recommended: Asphalt shingles, Leather.

Make it a practice to always read and insist your employees read and understand the MSDS that accompanies this product.

CAUTION - Avoid Alkaline Shock: Any detergent product that is applied to a hot surface stands a chance of producing alkaline shock. The surface is hot - a strong solution of detergent is applied - the water evaporates from the product before you have a chance to rinse - all resulting in a dull, streaked or tarnished surface which is often irreversible. Cool the surface down with water first then apply the product. On real hot days turn off the burner and wash with cold water.

Gloss Enhancers have made us famous! Order up a drum pack and see why!