

HEALTH AND SAFETY INFORMATION

Effects of Over Exposure:

- **Ingestion:** Damage to renal system may occur.
- **Eyes:** Causes severe eye irritation.
- **Skin:** Causes skin irritation.
- **Inhalation:** Causes respiratory tract irritation.

Emergency First Aid Procedures:

• **Ingestion:** Drink large quantities of water or milk and allow vomiting to occur. Examine victim for possible corrosive injury to mouth and throat and irrigate the areas with 1% Acetic Acid until alkali is neutralized. Seek medical attention immediately.

• **Eyes:** Remove contact lenses. Flush with copious amounts of water until all material is removed. If irritation develops or persists, seek medical attention immediately.

• **Skin:** Wash contacted area with soap and water. Remove contaminated clothing. If irritation persists, seek medical attention.

• **Inhalation:** Remove to fresh air. If breathing is difficult, oxygen may be given, preferably with a physician's advice. If not breathing, give artificial respiration, preferably mouth-to-mouth. If breathing difficulties persist seek medical attention.

IN CASE OF EMERGENCY CALL

CHEMTREC
1-800-424-9300

READ & UNDERSTAND

the Material Safety Data Sheet prior to use.
If no MSDS is present call: 1-800-346-4876

For Industrial or Professional Use Only.
KEEP OUT OF REACH OF CHILDREN & ANIMALS

WAX 'N SHINE

THIS SEALER WAX CONTAINS SILICONE HARDNERS AND HAS BEEN FORMULATED AS A PREMIUM FINISH GLOSS ENHANCER THAT HELPS TO REJUVINATE COMMERCIAL VEHICLE SURFACES.

**2.5 GALLON CONTAINER
MAKES 25 GALLONS of CONCENTRATE**
further dilution through an injector is required

BLENDING INSTRUCTIONS

Empty 2.5 gallons into a clean poly container that is large enough to hold 25 gallons of water. While stirring slowly fill the container with water. When full the product is ready to use.

MAKES GLASS SPARKLE!



USE INSTRUCTIONS

ALWAYS run a test pattern first and if acceptable continue as follows:

Apply using an Allison Super Suds Sucker chemical injector. In order to adjust to the proper concentration level always run a test pattern first on an inconspicuous area.

Quickly mist WAX N' SHINE from the bottom up and immediately rinse from the top down. Completely cover all areas including glass,. Apply only an amount that can be rinsed before the product dries. Avoid applying any chemical to a 'hot' surface. Cool down using cool, fresh water first.

This Quality Product is Manufactured by:

ENVIROSPEC

A Division of Hi-Tech Jetting Technologies, Inc.