

MIXING INSTRUCTIONS

Fill a clean 55-gallon drum approximately 30% to 40% full of warm water (if possible), place the nozzle of a high-pressure washer close to the bottom of the drum and start filling the drum with your pressure washer while adding the powder slowly. Limit pressure to 1000-1500 PSI as anything higher can blow apart the surfactants. When the drum is 80% to 90% full all of the powder should have been added, then add liquid (if Applicable) Continue filling until the drum is full. Product is now ready to use.

Helpful Hints- Use warm water (not to exceed 120 degrees Fahrenheit) will make powders go into solution easier. For quicker filling of drum use garden hose along with your pressure washer while filling. Do NOT overfill 55 gallon drum.

EnviroSpec products are manufactured in such a manner as to ensure that once the product is totally dissolved that it will stay in solution for a very long period of time.

For more information go to envirospec.com or call 800-346-4876