

## HEALTH AND SAFETY INFORMATION

### Effects of Over Exposure:

- **Ingestion:** Damage to renal system may occur.
- **Eyes:** Causes severe eye irritation.
- **Skin:** Causes skin irritation.
- **Inhalation:** Causes respiratory tract irritation.

### Emergency First Aid Procedures:

• **Ingestion:** Drink large quantities of water or milk and allow vomiting to occur. Examine victim for possible corrosive injury to mouth and throat and irrigate the areas with 1% Acetic Acid until alkali is neutralized. Seek medical attention immediately.

• **Eyes:** Remove contact lenses. Flush with copious amounts of water until all material is removed. If irritation develops or persists, seek medical attention immediately.

• **Skin:** Wash contacted area with soap and water. Remove contaminated clothing. If irritation persists, seek medical attention.

• **Inhalation:** Remove to fresh air. If breathing is difficult, oxygen may be given, preferably with a physician's advice. If not breathing, give artificial respiration, preferably mouth-to-mouth. If breathing difficulties persist seek medical attention.

IN CASE OF EMERGENCY CALL

**CHEMTREC**  
**1-800-424-9300**

### READ & UNDERSTAND

the Material Safety Data Sheet prior to use.  
If no MSDS is present call: 1-800-346-4876

For Industrial or Professional Use Only.  
KEEP OUT OF REACH OF CHILDREN & ANIMALS

# decktec

## CITRUS BASE OXYGENATOR FOR CLEANING NATURAL WOOD DECKS AND SHAKES



### BLENDING INSTRUCTIONS

Mix 1/2 to 1 pound of product per 1 gallon of hot water and stir vigorously until completely dissolved. Decktec works by oxygenation and should not be mixed with water until the operator is ready to perform the job.

### APPLICATION

There are several ways in which Decktec can be applied. For large areas we recommend a 115 volt or 12 volt SHURflo pump. When using a pump-up sprayer you should exercise caution since this product generates it's own oxygen resulting in internal pressure build-up in an enclosed container. Run a test pattern first and if acceptable apply a heavy coat to the area to be cleaned.

### DWELL TIME

Initial Coat - Spray onto surface and allow to stand for approximately 15 minutes. Rinse lightly before the brightener coat is applied.

### BRIGHTENER COAT

After the initial process is complete apply a second coat (brightener coat) and allow to stand for another 15 minutes and rinse well with low to medium pressure (1000 to 1500 P.S.I.)

This Quality Product is Manufactured by:

**ENVIROSPEC**

A Division of Hi-Tech Jetting Technologies, Inc.