

## HEALTH AND SAFETY INFORMATION

### Effects of Over Exposure:

- **Ingestion:** Damage to renal system may occur.
- **Eyes:** Causes severe eye irritation.
- **Skin:** Causes skin irritation.
- **Inhalation:** Causes respiratory tract irritation.

### Emergency First Aid Procedures:

• **Ingestion:** Drink large quantities of water or milk and allow vomiting to occur. Examine victim for possible corrosive injury to mouth and throat and irrigate the areas with 1% Acetic Acid until alkali is neutralized. Seek medical attention immediately.

• **Eyes:** Remove contact lenses. Flush with copious amounts of water until all material is removed. If irritation develops or persists, seek medical attention immediately.

• **Skin:** Wash contacted area with soap and water. Remove contaminated clothing. If irritation persists, seek medical attention.

• **Inhalation:** Remove to fresh air. If breathing is difficult, oxygen may be given, preferably with a physician's advice. If not breathing, give artificial respiration, preferably mouth-to-mouth. If breathing difficulties persist seek medical attention.

IN CASE OF EMERGENCY CALL

**CHEMTREC**  
**1-800-424-9300**

### READ & UNDERSTAND

the Material Safety Data Sheet prior to use.  
If no MSDS is present call: 1-800-346-4876

For Industrial or Professional Use Only.  
*KEEP OUT OF REACH OF CHILDREN & ANIMALS*

# HOOD-PRO

## THE INDUSTRY'S ONLY **NON-CAUSTIC** EXHAUST HOOD CLEANER



**MAKES 110 GALLONS**  
of a **HEAVY DUTY CONCENTRATE** or **55 GALLONS** of a **SEVERE DUTY EXTRACT**

### BLENDING INSTRUCTIONS

Remember - Warm water (not to exceed 120°F) will always make powders go into solution easier. If cold water is used manual agitation may be necessary.

EnviroSpec products are manufactured in such a manner as to insure that once the product is totally dissolved that it will stay in solution for a very long period of time.

When mixing, fill a clean poly drum approximately 50% full of warm water and place the nozzle of a high pressure washer close to the bottom and continue filling while adding the powder slowly. Limit pressure to 1000-1500 PSI as anything higher can blow apart the surfactants. When the drum is 90% full all of the powder should have been added. Continue filling until the drum is full. Product is now ready to use.

### USE INSTRUCTIONS

ALWAYS run a test pattern first and if acceptable continue as follows:

This product is designed to spray at full concentration onto the exhaust hood surface. Allow to dwell for approximately 1-2 minutes and high pressure rinse. Depending on the frequency of the cleaning process an additional application may be required.

For best results apply using a ShurFLO or EverFLO 12V or 115V chemical pump.

This Quality Product is Manufactured by:

**ENVIROSPEC**

A Division of Hi-Tech Jetting Technologies, Inc.