

HEALTH AND SAFETY INFORMATION

Effects of Over Exposure:

- **Ingestion:** Damage to renal system may occur.
- **Eyes:** Causes severe eye irritation.
- **Skin:** Causes skin irritation.
- **Inhalation:** Causes respiratory tract irritation.

Emergency First Aid Procedures:

• **Ingestion:** Drink large quantities of water or milk and allow vomiting to occur. Examine victim for possible corrosive injury to mouth and throat and irrigate the areas with 1% Acetic Acid until alkali is neutralized. Seek medical attention immediately.

• **Eyes:** Remove contact lenses. Flush with copious amounts of water until all material is removed. If irritation develops or persists, seek medical attention immediately.

• **Skin:** Wash contacted area with soap and water. Remove contaminated clothing. If irritation persists, seek medical attention.

• **Inhalation:** Remove to fresh air. If breathing is difficult, oxygen may be given, preferably with a physician's advice. If not breathing, give artificial respiration, preferably mouth-to-mouth. If breathing difficulties persist seek medical attention.

IN CASE OF EMERGENCY CALL

CHEMTREC
1-800-424-9300

READ & UNDERSTAND

the Material Safety Data Sheet prior to use.
If no MSDS is present call: 1-800-346-4876

For Industrial or Professional Use Only.
KEEP OUT OF REACH OF CHILDREN & ANIMALS

PREP-EZZ

PRE-PAINT SURFACE PREP

NON-CAUSTIC • REMOVES OXIDATION

20 LB KIT MAKES 40 GALLONS

of a **HEAVY DUTY CONCENTRATE** or **55 GALLONS** of a **SEVERE DUTY EXTRACT**

BLENDING INSTRUCTIONS

Remember - Warm water (not to exceed 120°F) will always make powders go into solution easier. If cold water is used manual agitation may be necessary.

EnviroSpec products are manufactured in such a manner as to insure that once the product is totally dissolved that it will stay in solution for a very long period of time.

When mixing, fill a clean poly drum approximately 50% full of warm water and place the nozzle of a high pressure washer close to the bottom and continue filling while adding the powder slowly. Limit pressure to 1000-1500 PSI as anything higher can blow apart the surfactants. When the drum is 90% full all of the powder should have been added. Continue filling until the drum is full. Product is now ready to use.

USE INSTRUCTIONS

ALWAYS run a test pattern first and if acceptable continue as follows:

Apply using an Allison Super Suds Sucker chemical injector. In order to adjust to the proper concentration level always run a test pattern first on an inconspicuous area.

Apply chemical from the bottom up and rinse from the top down. Apply only an amount that can be rinsed before the product dries on any surface including glass. Avoid applying any cleaning chemical to a 'hot' surface. Cool down using cool, fresh water first.

This Quality Product is Manufactured by:

ENVIROSPEC

A Division of Hi-Tech Jetting Technologies, Inc.